

XR A330

PGM MODE ENTER: {2711} {.] {@/FOR} {1 or 2 or 3 or 4} {@/FOR} {50000} {@/FOR}
{1} {CASH}

XE A101

Z/PGM MODE ENTER: {9} {#/SBTL} {1 or 2 or 3 or 4} {@/TM} {50000} {@/TM}
{CASH}

ER A410, A420, A430, , A440, A450, A460, A470, A570, A610

PGM2 MODE ENTER: {2711} {.] {@/FOR} {1 or 2 or 3 or 4} {@/FOR} {50000} {@/FOR}
{1} {CASH}